

Determining sizes :

It's very easy with the **Theo Boot®**:

Measure the bottom of the hoof at it's widest point, find the corresponding measurement on the chart below and the size to the left is the **Theo Boot®** size you need for your animal. The length of the hoof shoe can be changed with the open endet fitting of the adjustable back strap.

from Sept. 2008:

available in sizes # 5, 6, 7, 8

TB #	size	hoof width in cm
1		4,5 - 6,5
2		6,5 - 8,0
3		8,0 - 9,5
4		9,0 - 10,5
5		10,0 - 11,0
6		11,0 - 12,5
7		12,0 - 13,5
8		14,0 - 15,5
9		15,0 - 16,5
10		16,5 - 18,0
11		18,0 - 19,5
12		19,5 - 21,0
13		21,0 - 23,0

For more informations contact our website

www.hufschuhdokter.de

Technical modifications and changes of the size table are subject to change without notice.

up to date: September 2008

Theo Boot®



Hufschuhdokter

Theo Rüspler

Hainstraße 24

35457 Lollar-Salzböden

+49(0)6406-4758

Tel.:

+49(0)6406-830539

Fax:

+49(0)171-8159159

Mobil :

mail@hufschuhdokter.de

www.hufschuhdokter.de

User information + price list

Theo Boot®

... the innovative hoof protection!

Made in Germany

by the

Horse shoe Doctor

Patented and registered product!



Theo Boot® assembled at the factory

WeLo

Werkstatt Lollar

WeLo is an acknowledged factory for the employment of handicapped community by „Help for life Giessen“

Theo Boot®

... the ideal

hoof shoe for riding and coach driving for horses, donkeys and mules.

~ innovative, long-lasting material

The Theo Boot® is made out of a modern plastic material including a robust material that allows easy movement for the animal.

~ a carling fit

The Theo Boot® is one of the very few hoof shoes that are fastened exclusively on the hard wall of the hoof. The height off the bars should have a minimum of 25 mm, shouldn't be drawn in or too flat, for guaranteeing a secure fit to the hoof.

~ width of the hoof

The width of the hoof will correspond with the inside measurement of the Theo Boot®.

~ length of the hoof

The length of the hoof is not an important factor with the Theo Boot®. The length adjustment is done variably by the modern ratchet adjustable strap. During riding breaks, the strap should be periodically checked for a secure fit and readjusted if necessary.

~ plastic screws

The sole is fastened to the Theo Boot® with plastic screws and should be checked regularly for a secure fit. Please use only the special Phillips screwdriver size **PZ 3**

(available at our shop or any local business, selling hand tools).

These special screws mustn't be any tighter than 2,0 Nm.

~ sole replacement

Replacing the sole is easy to do by yourself.

Pre-warm the Theo Boot®s half an hour in advanced in a 35°-50°C (95°-122°F) warm water bath, for an easier loosening of the screws.

First loosen the screws on the sides, the middle screw in the front afterwards. Only use the above mentioned Phillips screwdriver with the recommended pressure.

Attach the replacement sole in the opposite order that the old sole was removed, to the Theo Boot®: fasten the front middle screw first through the opening in the toe.

To avoid damage to the screws or hoof shoe mounts, first pre-moisten the screws for an easier fit and make sure screws are not used in an improper angle!

- Only for patented original Theo Boot® – soles use
- Repairs only with original Theo Boot® – parts (for warranty reasons)

Please ask for the detailed owner's manual for the Theo Boot®.



-All prices include. 19 % tax – plus shipping

Prices: for the Theo Boot®

<u>per piece</u>	<u>each in € (Euro)</u>
with summer sole	75,-
with summer-/winter sole and 4 spikes or posts	95,-
with summer-/winter sole and 2 spikes or posts	90,-
with winter sole and 4 spikes or posts	85,-
with winter sole and 2 spikes or posts	82,50
only top part (without sole)	40,-
only summer sole including 8 plastic screws	17,-
only winter sole incl. 8 plastic screws + 4 spikes or posts	22,-
only winter sole incl. 8 plastic screws + 2 spikes or posts	19,50
Phillips screwdriver PZ 3 (for sole)	6,-
Phillips screwdriver PH 2 (for t-band)	5,-
Hole punch, 5 mm	5,-